

The following instructions apply to the 100cm, 74cm and 60cm 1-chamber SpeedDock airlocks*. You will need:

- ◆ 1 x SpeedFrame chambers (2 top/bottom sections and 4 poles)
- ◆ 1 x SpeedDock single chamber tent
- ◆ 22 x small SpeedClips®


1. Assemble 1 SpeedFrame® chamber as shown in Figure 1. For non-SpeedDock frames, remove any plastic end caps on the top and bottom sections that project beyond the edge of the frame.

**The HSE regulations require the use, wherever possible, of 100cm by 2m airlocks*




Figure 1 – SpeedFrame® Assembly

2. Carefully remove the tent from its packaging. Starting at the end with the weighted flap showing, wrap the **top** polythene strip ① over the top bar, align the seam on the side with the inside edge of the frame, align the top seam with the underside of the top bar and secure by pushing 3 small clips over the top of the frame



3. Still at the same end, wrap the side strip ② around the poles and attach 4 small Clips down each side, being careful to make sure that the clips face the right way (out to the side). Note that they can be adjusted after the SpeedDock tent has been hung.



4. Note that the seam on the tent should align with the inside edge of the pole

- Now wrap and clip the rest of the tent to the frames. Working backwards the polythene edge strips should wrap around behind the poles and then are secured with the clips as they come round and over to the front and pulling the tent as tight as possible at each stage.






Figure 2 – SpeedDock® Tent Clip Positioning

- Cut the second entrance hole for the airlock in one of the three marked positions and attach the loose weighted polythene flap supplied to the inside. The flap has a self-adhesive strip to help with positioning but you may need to use adhesive tape in addition to ensure that it is securely attached. Note that it should be hung on the inside of the first chamber with the warning signs facing outwards.

- Where required, attach an air control/night flap to the outside of the entrance. CSD can supply these flaps ready to hang.

- The single chamber is now ready to use on its own or attach to other chambers.

9. Thoroughly inspect the SpeedDock unit before first use and then daily to ensure no damage is present that could affect its proper functioning.

SpeedDock®

CSD Systems Limited
 Pantiles Chambers
 85 High Street
 Tunbridge Wells
 Kent TN1 1XP
 UK

T: +44 (0) 1892 614 366 F: +44 (0) 1892 535 475
www.speeddock.com info@cspdsystems.co.uk

Call us on 0800 083 0637 or visit
www.speeddock.com
 for details of our full product range
 and special offers